

S23XR/1T5 FSR CEILING INSTALLATION INSTRUCTIONS




STEP 2: REMOVE RELECTORS AND BALLAST COVERS FROM ALL FIXTURES. FOR RUNS, REMOVE KNOCK OUTS ON ENDCAPS FOR THROUGH WIRING PURPOSES (WHERE APPLICABLE).

REMOVE ALL TIE ROD KNOCK OUTS ON HOUSINGS.
REMOVE ACCESS PLATE KNOCK OUT(S) TO BE USED FOR FEEDS.



PERFORATED RAILS ALREADY INSTALLED ON HOUSING. RIVET (1) BRACKET ON EACH SIDE OF AN INDIVIDUAL FIXTURE. FIRST AND LAST FIXTURE IN A RUN APPLICATION. RIVET (1) BRACKET ON THE OUTER END OF THE 3: RIVET PERFORATED END BRACKET ONTO SIDE



STEP 5: (FOR RUNS ONLY) JOIN ADJACENT FIXTURES USING HOLES IN END CAPS

STEP 4: INSTALL FIXTURE SECTIONS (ONE AT A TIME) INTO THE CEILING FROM BELOW. PUSH TIE RODS THROUGH REMOVED KNOCK OUTS. INSTALL TIE ROD NUT AND TIGHTEN UNTIL THE TOP OF THE PERFORATED FLANGES CONTACTS THE SURFACE OF THE CEILING.
PULL FEED WIRE(S) THROUGH REMOVED FEED KNOCK OUT(S).


54.

و چ د


TIE ROD NUT -

0

TIE ROD



STEP 6: WIRE FIXTURES. REINSTALL THE REFLECTORS AND BALLAST COVERS. INSTALL THE LAMPS. SECURE FSR RAILS TO SHEETROCK WITH FASTENING HARDWARE. FEATHER SPACKLE OVER PERFORATED FLANGES FROM THE CEILING TO THE EDGE OF THE FIXTURE HOUSING TO CREATE A SEAMLESS APPEARANCE.



SERIES :	
SERIES 23XR/1T5 FLANGELESS SHEETROCK (FSR)	INSTRUCTIONS FOR SERIES



			IES
(1)	DA		DR
3/4/09	DATE	JH	AWN BY
NONE	SCALE		DRAWN BY APPROVED
SHEET 3 OF 3		INSTALLATION INSTRUCTIONS	