

WARNINGS

- 1) **WARNING!** – Risk of Fire/Electric Shock. Disconnect power at fuse or circuit breaker before installing or servicing.
- 2) **WARNING!** – Risk of Fire/Electric Shock. If not qualified, consult an electrician.
- 3) **WARNING!** – Avoid contact with LED modules.

NOTES

- 1) **NOTE!** – This product must be installed in accordance with local/ national electrical codes.
- 2) **NOTE!** – Only those open holes indicated in the photographs and/or drawings may be made or altered as a result of kit installation. Do not leave any other open holes in an enclosure of wiring or electrical components.
- 3) **NOTE!** – To prevent wiring damage or abrasion, do not expose wiring to edges of sheet metal or any sharp objects.
- 4) **NOTE!** – Disconnect all power before proceeding.

INSTALLATION

- ① **Install BACK PAN to J-Box (4x4" min.) (by others). Pan allows for Vertical or Horizontal mounting.**
NOTE: Mounting hardware to be provided by Contractor
- ② **Wire to requirements following all National and Local Electrical Codes.**
- ③ **Slot SCONCE HOUSING onto BACK PAN as shown and rotate into position.**
- ④ **Install (1x) SCREW (included) to secure SCONCE HOUSING.**

